

## Ferrite Choke Installation Instructions

Document Number 7975-A2-GZ40-00

July 1998

---

## Overview

This document describes the procedure for installing a ferrite choke onto the DTE cable of the Hotwire Model 7975 M/SDSL standalone termination unit.

### CAUTION:

**All ferrite chokes that are supplied must be installed following these instructions to ensure compliance with FCC Part 15, VCCI, and CISPR22 rules.**

## Installation

### ► Procedure

To install the ferrite choke onto the DTE cable:

1. Open the ferrite choke and place it around the cable as close to the cable connector as possible.
2. Close the two halves around the cable and snap the choke shut, pressing down on the plastic latch to secure it in place.
3. Add a tie wrap (not included) as shown to prevent the ferrite choke from slipping down the cable.

