

## 7995-A2-374 SHDSL-Serial NTU

### Quick Installation Instructions

Document Number 7995-A2-GZ10-00

September 2004

## Installation

- 1 Connect the LINE port to your DSL line with an RJ45 connector cable.
- 2 Connect the V.35 interface to your router.
- 3 Connect the LAN port to the SNMP management network with an RJ45 connector cable.
- 4 Connect the Console port to a VT100 compatible terminal or PC COM port with an RS232 cable.
- 5 Connect the Power jack to the power adapter with the power adapter cord. Attach the power adapter to the wall outlet or other AC source. Then turn on the power switch on the rear panel.

It can take a couple of minutes for the NTU to link up with its partner unit. The link is up when the DSL LOS indicator LED is off.

See the User's Guide for management and troubleshooting information.

